

---

# Comprehensive Measurement Protocol

## Metal-HZO(10nm)-Metal Ferroelectric Memristor

---

### Research Protocol Documentation

January 22, 2026

### Contents

<b>1</b>	<b>Material System Overview</b>	<b>2</b>
<b>2</b>	<b>Instrument Requirements (Best Case Scenario)</b>	<b>2</b>
2.1	Primary Electrical Characterization . . . . .	2
2.2	Advanced Characterization . . . . .	2
<b>3</b>	<b>Phase 0: Initial Device Screening &amp; Wake-Up</b>	<b>3</b>
3.1	Test 0.1: Pre-Measurement Inspection . . . . .	3
3.2	Test 0.2: Wake-Up Cycling . . . . .	3
<b>4</b>	<b>Phase 1: Ferroelectric Characterization</b>	<b>4</b>
4.1	Test 1.1: Polarization-Electric Field (P-E) Loop . . . . .	4
4.2	Test 1.2: PUND Measurement . . . . .	4
4.3	Test 1.3: C-V Butterfly Curve . . . . .	4
<b>5</b>	<b>Phase 2: Multi-Level States (Neuromorphic Weights)</b>	<b>5</b>
5.1	Test 2.1: Partial Polarization Switching . . . . .	5
5.2	Test 2.2: State-Wise Retention . . . . .	5
<b>6</b>	<b>Phase 3: Synaptic Behavior (Neuromorphic)</b>	<b>5</b>
6.1	Test 3.1: LTP and LTD . . . . .	5
6.2	Test 3.2: Spike-Timing-Dependent Plasticity (STDP) . . . . .	6
<b>7</b>	<b>Phase 4: Reliability &amp; Endurance</b>	<b>7</b>
7.1	Test 4.1: Fatigue (Endurance) Cycling . . . . .	7
7.2	Test 4.2: Temperature Retention (Arrhenius Plot) . . . . .	7
<b>8</b>	<b>Novel Neuromorphic Demonstrations (Future Work)</b>	<b>7</b>
8.1	Proposal 1: Reservoir Computing . . . . .	7
8.2	Proposal 2: Asymmetric STDP . . . . .	7
8.3	Proposal 3: 5-Bit Weight Storage . . . . .	7
<b>9</b>	<b>Appendix: Full Fatigue Script (Keithley TSP)</b>	<b>7</b>

# 1 Material System Overview

**Target System:**  $\text{Hf}_x\text{Zr}_{1-x}\text{O}_2$  (HZO) Ferroelectric Memristor Stack.

- **Top Electrode (TE):** TiN, Pt, W, or  $\text{RuO}_2$  (10 – 50 nm).
- **Ferroelectric Layer:** HZO (10 nm,  $x \approx 0.5$ ).
- **Bottom Electrode (BE):** TiN, Pt, W, or  $\text{RuO}_2$  (10 – 50 nm).
- **Substrate:** Si,  $\text{SiO}_2/\text{Si}$ , or Sapphire.

## Neuromorphic Advantages of HZO

- **Non-Volatile:** Retains state without power due to spontaneous polarization.
- **CMOS Compatible:** Unlike PZT or BTO, HZO integrates into standard silicon flows.
- **Scalable:** Robust ferroelectricity down to  $< 10$  nm thickness.
- **Energy Efficient:** Low switching energy ( $\sim 10$  fJ/bit potential).

# 2 Instrument Requirements (Best Case Scenario)

## 2.1 Primary Electrical Characterization

**Semiconductor Parameter Analyzer (SPA):** Keithley 4200A-SCS

- 4 SMU channels for simultaneous measurements.
- Current resolution: 1 fA (critical for low leakage HZO).
- Built-in Pulse Measurement Unit (PMU) for pulses down to 200 ns.

**Ferroelectric Tester:** Radiant Precision Premier II

- **Critical Requirement:** Measures charge ( $Q$ ) directly, not just current.
- Automated P-E loops, PUND protocols, and fatigue testing up to  $10^{10}$  cycles.

**Impedance Analyzer:** Keysight E4990A (20 Hz - 120 MHz)

- Required for C-V butterfly curves and dielectric constant extraction.

## 2.2 Advanced Characterization

**Pulse Generator & Oscilloscope:** Keysight 33600A + DSOX6004A (6 GHz).

**Cryogenic Probe Station:** Lake Shore CRX-4K (4 K to 475 K) for Arrhenius plots.

**Piezoresponse Force Microscopy (PFM):** Asylum Research Cypher ES for domain imaging.

### 3 Phase 0: Initial Device Screening & Wake-Up

#### CRITICAL: Wake-Up Effect

As-deposited HZO is often in a mixed phase (monoclinic/tetragonal). It **must** be electrically cycled to transition into the ferroelectric orthorhombic phase. Without wake-up, polarization ( $P_r$ ) will be negligible.

#### 3.1 Test 0.1: Pre-Measurement Inspection

1. Visual inspection for shorts/damage.
2. Measure pristine capacitance at 1 kHz (check for open circuits).
3. Check leakage at 0.5 V (should be  $< 1$  nA for a good device).

#### 3.2 Test 0.2: Wake-Up Cycling

##### Parameters:

- **Frequency:** 10 kHz (Triangular/Bipolar).
- **Amplitude:**  $\pm 3$  V to  $\pm 5$  V.
- **Cycles:**  $10^4$  to  $10^5$  cycles.
- **Stop Condition:** When remnant polarization ( $P_r$ ) stabilizes.

```

1 - WAKE-UP CYCLING FOR HZO
2 reset()
3 smu.measure.terminals = smu.TERMINALS_REAR
4 local wake_voltage = 4.0
5 local num_cycles = 10000
6 local frequency = 10000
7 local half_period = 1 / (2 * frequency)
8
9 smu.source.func = smu.FUNC_DC_VOLTAGE
10 smu.source.limiti = 100e-6
11 smu.source.output = smu.ON
12
13 for cycle = 1, num_cycles do
14     - Positive half-cycle
15     smu.source.levelv = wake_voltage
16     delay(half_period)
17     - Negative half-cycle
18     smu.source.levelv = -wake_voltage
19     delay(half_period)
20 end
21 smu.source.levelv = 0
22 smu.source.output = smu.OFF
23 print("Wake-Up Complete")

```

Listing 1: TSP Script for Wake-Up Cycling

## 4 Phase 1: Ferroelectric Characterization

### 4.1 Test 1.1: Polarization-Electric Field (P-E) Loop

**Instrument:** Radiant Tester (Preferred) or Keithley 4200A (via Integration).

**Goal:** Extract Remnant Polarization ( $P_r$ ) and Coercive Field ( $E_c$ ).

**Procedure:** Sweep voltage  $0 \rightarrow +V_{max} \rightarrow -V_{max} \rightarrow 0$ . If using Keithley (SMU), measure Current ( $I$ ) vs Time ( $t$ ) and integrate:

$$P = \frac{1}{A} \int I(t) dt \quad (1)$$

Where  $A$  is the device area.

### 4.2 Test 1.2: PUND Measurement

**Purpose:** To separate true ferroelectric switching from leakage current and dielectric capacitance.

**Pulse Sequence:**

1. **Preset:** Saturates device to  $+P_r$ .
2. **P (Positive):** Switches state (Includes Switching Current + Leakage).
3. **U (Up):** Non-switching (Includes Leakage only).
4. **N (Negative):** Switches state to negative.
5. **D (Down):** Non-switching negative.

**Calculation:**

$$Q_{sw} = \frac{(Q_P - Q_U) + (Q_D - Q_N)}{2} \quad (2)$$

### 4.3 Test 1.3: C-V Butterfly Curve

**Instrument:** LCR Meter / Impedance Analyzer.

**Parameters:**

- Frequency: 1 kHz - 1 MHz.
- AC Amplitude: 30 mV (Small signal).
- DC Bias: Sweep  $\pm 5$  V.

**Success Criteria:** Characteristic "butterfly" shape where capacitance peaks at the coercive voltages ( $\pm V_c$ ).

## 5 Phase 2: Multi-Level States (Neuromorphic Weights)

### 5.1 Test 2.1: Partial Polarization Switching

To emulate synaptic weights, we need analog conductance states, not just binary 0/1.

**Protocol (Incremental Pulse Programming):**

1. Reset device to Negative State (-5V).
2. Apply positive pulse stream with increasing amplitude (e.g., 1.0V, 1.1V... 3.0V).
3. Read conductance ( $G = I/0.5V$ ) after each pulse.

```

1 - MULTI-LEVEL PULSE PROGRAMMING
2 local v_start = 1.0
3 local v_stop = 3.0
4 local v_step = 0.1
5 local read_voltage = 0.5
6
7 for v_pulse = v_start, v_stop, v_step do
8   - Program
9   smu.source.levelv = v_pulse
10  delay(0.001) - 1ms pulse
11  smu.source.levelv = 0
12  delay(0.01)
13
14  - Read
15  smu.source.levelv = read_voltage
16  local i_read = smu.measure.i()
17  smu.source.levelv = 0
18
19  print(string.format("Pulse: %.2f V, Conductance: %.2e S", v_pulse, i_read/
20    read_voltage))
end

```

Listing 2: TSP Script for Multi-Level Programming

### 5.2 Test 2.2: State-Wise Retention

Unlike binary memory, each intermediate state must be stable.

- Program to State  $N$  (e.g., 50% polarization).
- Read Conductance continuously for  $10^4$  seconds.
- **Pass criteria:** Drift  $< 5\%$  over the measurement period.

## 6 Phase 3: Synaptic Behavior (Neuromorphic)

### 6.1 Test 3.1: LTP and LTD

**LTP (Long-Term Potentiation):** Gradual conductance increase.

**LTD (Long-Term Depression):** Gradual conductance decrease.

**Protocol:**

- Apply 50 identical pulses (+2V, 100ms) for LTP.
- Apply 50 identical pulses (-2V, 100ms) for LTD.
- **Metric:** Linearity and Dynamic Range ( $G_{max}/G_{min}$ ).

## 6.2 Test 3.2: Spike-Timing-Dependent Plasticity (STDP)

Emulates biological learning rules (Hebbian Learning).

$$\Delta G = f(\Delta t) \quad \text{where} \quad \Delta t = t_{post} - t_{pre} \quad (3)$$

- If  $\Delta t > 0$  (Causal): Potentiation (Synapse strengthens).
- If  $\Delta t < 0$  (Anti-causal): Depression (Synapse weakens).

## 7 Phase 4: Reliability & Endurance

### 7.1 Test 4.1: Fatigue (Endurance) Cycling

**Requirement:** HZO must survive switching cycles for computing applications.

- **Target:**  $> 10^9$  cycles.
- **Frequency:** 1 MHz (using Pulse Generator).
- **Monitor:**  $P_r$  and On/Off ratio every logarithmic decade ( $10^3, 10^4, \dots$ ).

### 7.2 Test 4.2: Temperature Retention (Arrhenius Plot)

Accelerated aging to predict 10-year retention.

1. Measure retention decay  $\tau$  at  $85^\circ\text{C}$ ,  $100^\circ\text{C}$ ,  $125^\circ\text{C}$ .
2. Fit to Arrhenius Equation:

$$\tau(T) = \tau_0 \exp\left(\frac{E_a}{k_B T}\right) \quad (4)$$

3. Extrapolate to room temperature ( $25^\circ\text{C}$ ).

## 8 Novel Neuromorphic Demonstrations (Future Work)

### 8.1 Proposal 1: Reservoir Computing

Utilize the inherent non-linearity and short-term memory of the HZO film to process temporal data (e.g., speech recognition) without training the HZO layer itself, only the readout layer.

### 8.2 Proposal 2: Asymmetric STDP

Demonstrate biologically realistic STDP where Potentiation is stronger than Depression using asymmetric pulse engineering (e.g., +3V Set / -2V Reset).

### 8.3 Proposal 3: 5-Bit Weight Storage

Attempt to stabilize 32 distinct conductance levels ( $2^5$ ) with high yield, surpassing standard 3-bit or 4-bit memristive demonstrations.

## 9 Appendix: Full Fatigue Script (Keithley TSP)

```

1 - ENDURANCE/FATIGUE TESTING
2 reset()
3 smu.measure.terminals = smu.TERMINALS_REAR
4
5 local set_voltage = 5.0
6 local reset_voltage = -5.0
7 local pulse_width = 1e-3
8 local read_voltage = 0.5
9 local num_cycles = 1000000          - 1 Million Cycles
10 local read_interval = 1000         - Check every 1k cycles
11
12 smu.source.func = smu.FUNC_DC_VOLTAGE
13 smu.source.output = smu.ON
14

```

```
15 print("Endurance Cycling Started")
16
17 for cycle = 1, num_cycles do
18     - SET Pulse
19     smu.source.levelv = set_voltage
20     delay(pulse_width)
21     smu.source.levelv = 0
22     delay(0.01)
23
24     - RESET Pulse
25     smu.source.levelv = reset_voltage
26     delay(pulse_width)
27     smu.source.levelv = 0
28     delay(0.01)
29
30     - Periodic Readout
31     if cycle % read_interval == 0 then
32         smu.source.levelv = read_voltage
33         local i_read = smu.measure.i()
34         smu.source.levelv = 0
35         print(string.format("Cycle %d: I_read = %.2e A", cycle, i_read))
36     end
37 end
38
39 smu.source.output = smu.OFF
40 print("Endurance Test Complete")
```

Listing 3: Endurance Test Script